

# AROMAMIST®

## PETITE

Handheld Aromatherapy  
Personal Diffuser



Aromatherapy  
anywhere, anytime

## Warranty

**One Year Warranty** - Aromamatic Products Pty Ltd guarantees the Diffuser for a period of one year from the date of purchase if found defective by the manufacturer or their approved agent. This guarantee does not include replacement of a damaged unit or broken by internal or external damage, or the USB power cord, incorrect use of the Diffuser will nullify any warranty claim. Please return the unit to the place of purchase with your receipt to validate a warranty claim.

Aromamatic Products Pty Ltd  
P O Box 840 S.B.C. Southport Qld 4215  
[www.aromamatic.com.au](http://www.aromamatic.com.au)

**NOTE:** As a fine mist is produced, moisture residue may form on flat surfaces.

## Cleaning Instructions

The diffuser **MUST** be cleaned at regular intervals to remove impurities and residue to ensure the correct operation of the unit.

Before cleaning, remove the USB cable and the top cover. Lightly rinse the water tank with fresh water and leave to air dry. **Gently** use a cotton swab in the water tank to remove any buildup of residue if necessary.

**DO NOT** immerse or place into water or other liquids.

### Q & A - Why is there no mist?

Make sure the unit is fully charged.

Check and refill the water tank.

Ensure the external outlet and the internal valve are free of any buildup of residue.



Handheld  
Size



Fits in your  
Bag



Continuous mist  
for 60 seconds



Silent Cool  
Mist




Essential Oil  
and Blends




Facial  
Refresher

## Product Operation




- Top Cover
- Max Water Level
- Air Outlet
- Mist Slide Button
- USB Cable


Size: 32mm x 32mm x 100mm  
Water Capacity: 15ml  
Voltage: DC 5V Power: 1W




**1.** Twist top cover to the right (counterclockwise) to remove.



**2.** Fill with tap water up to the max fill line, then add 2 drops of essential oil.



**3.** Replace the top cover. Make sure cover is tight and secure.




Plug in the USB cable at bottom to re-charge the unit. A red light will come on.

## Modes of Operations

**Slide down:** To turn on the unit with blue LED light. Mist continuous mode (60 secs).

**Slide up:** To turn off the unit.

**NOTE:** When battery is run down, LED light flashes in blue color.



For more information see website [www.aromamatic.com.au](http://www.aromamatic.com.au)